

frontrow™
pro digital



USER GUIDE

940R Receiver

940TM Pendant Microphone

950H Pass-Around Microphone

950C Microphone Charger

Contents

Important Safety Instructions	1
Electrical Warnings	2
950C Charger	
Chapter 1 Features	3
Chapter 2 Charger Setup	4
940TM Pendant Microphone	
Chapter 3 Features	5
Chapter 4 Installing Battery and Charging	6 - 7
Chapter 5 Using	8
950H Pass-Around Microphone	
Chapter 6 Features	9
Chapter 7 Setting channel, installing battery and charging	10 - 11
Chapter 8 Using Pass-Around Microphone	12 - 13
Chapter 9 Using a Second Transmitter	14
940R Pro Digital Receiver	
Chapter 10 Features	15
Chapter 11 Activate Receiver and Transmitter	16
Chapter 12 Automatic Feedback Suppression and OptiVoice	17
Chapter 13 Connecting to other Classroom Media	18 - 19
Chapter 14 Auxiliary Output - Rebroadcasting to Personal FM Receivers	20
Chapter 15 Troubleshooting	21
Chapter 16 Regulatory	22



The FrontRow Pro Digital is manufactured to conform to the most stringent European guidelines for consumer products (RoHS) – it is produced using a process free of lead and other materials harmful to the environment.



The FrontRow Pro Digital is listed with Educational Underwriters, a non-profit organization committed to serving educators seeking to meet No Child Left Behind (NCLB) requirements and to establishing best practices in education. EdU reviews the research behind educational programs and products to verify that they meet NCLB requirements and high educational standards. For additional information regarding Educational Underwriters, go to www.educationalunderwriters.org.



The FrontRow Pro Digital System conforms to the stringent electrical safety standards set by Underwriters Laboratory (UL).



Your 940TM Pendant Microphone, 950H Pass-Around Microphone, and 950C Charger use SmartCharge technology. The microphone will only charge the "silver-sleeve", auto-sensing battery that comes with our microphone. If an incompatible battery is detected, the microphone will not let you charge the battery. This prevents accidental damage.

You may use standard alkaline batteries in your microphones if you forget to charge them, but do not attempt to charge alkaline batteries separately. To ensure proper charging, always be sure that only "silver sleeve" auto-sensing batteries are installed.

IMPORTANT SAFETY INSTRUCTIONS

1. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
2. Read these instructions.
3. Keep these instructions.
4. Heed all warnings.
5. Follow all instructions.
6. Do not use this apparatus near water.
7. Clean only with dry cloth.
8. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
9. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
10. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
11. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
12. Only use attachments/accessories specified by the manufacturer.
13. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
14. Unplug this apparatus during lightning storms or when unused for long periods of time.
15. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



ELECTRICAL WARNINGS

1. Avoid Abuse to the Power Supply

To reduce risk of electric shock, unplug the power supply from outlet before attempting any maintenance or cleaning. Turn off controls will not reduce this risk.

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

DO NOT disassemble the power supply. Return the apparatus to Phonic Ear FrontRow for qualified service and repair if service or repair is required. Incorrect reassembly may result in a risk of electric shock or fire.

DO NOT expose the power supply to rain, snow, water, gas, oil, etc.

DO NOT operate the power supply if it has received a sharp blow, been dropped, or otherwise damaged in any way; return the apparatus to Phonic Ear FrontRow for qualified service and repair.

DO NOT block or cover the apparatus and impede ventilation.

DONOT expose batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire, or the like.

2. Proper Use of the Power Supply and Wiring

An extension cord should not be used unless absolutely necessary. Use of improper extension cord could result in a risk of fire and electric shock. The cord **MUST** be plugged into a grounded outlet. Make sure it is properly wired, in good electrical condition, and wire size is large enough for AC ampere rating of the power supply or charger as specified below. AWG = American Wire Gauge.

To reduce risk of damage to plug and cord when disconnecting the power supply or charger, **ALWAYS** pull on plug - **NEVER** on cord.

Locate cord so that it will not be stepped on, tripped over, or otherwise subject to damage or stress. **DO NOT** lay extension cord on charger.

DO NOT operate the power supply with damaged cord or plug - replace them immediately.

ELECTRICAL SAFETY INFORMATION:



PRECAUTIONS & SAFETY RECOMMENDATIONS

Follow Manufacturers' Recommendations

Before using the receiver and power supply, read all instructions for, and caution markings on the receiver and power supply and in this user guide.

